


NINTENDO CLASSIC MINI



**ENTERTAINMENT
SYSTEM™**



© 2017 Nintendo. All rights reserved.

For more information, visit www.nintendo.com/classicmini

Health and Safety Information

Please read and observe the health and safety information. Failure to do so could result in injury or damage. Adults should supervise the use of this product by children.

⚠️ WARNING – SEIZURES

- Some people (about 1 in 4000) may have seizures or blackouts triggered by light flashes or patterns, and this may occur while they are watching TV or playing video games, even if they have never had a seizure before.
- Anyone who has ever experienced seizures, loss of awareness or any other symptom linked to an epileptic condition should consult a doctor before playing video games.
- Parents or legal guardians should monitor children when they play video games. Stop playing and consult a doctor if you or your child have any unusual symptoms, such as: **convulsions, eye or muscle twitching, loss of awareness, altered vision, involuntary movements or disorientation.**

❗ To reduce the likelihood of a seizure when playing video games, follow these precautions:

1. Do not play if you are tired or need sleep.
2. Play in a well-lit room.
3. Take a break of 10 to 15 minutes every hour.

⚠️ WARNING – EYE STRAIN AND MOTION SICKNESS

Playing video games can make your eyes hurt after a sustained period of time. Playing video games can also cause motion sickness in some players. Follow these instructions to avoid eye strain, dizziness or nausea:

- Avoid excessively long play sessions. Parents or legal guardians should monitor their children for appropriate play.
- Take a break of 10 to 15 minutes every hour, even if you don't think you need it.
- If your eyes become tired or sore while playing, or if you feel dizzy, nauseated or tired, stop and rest for several hours before playing again.
- If you continue to have any of the above symptoms or other discomfort during or after play, stop playing and see a doctor.

⚠️ WARNING – REPETITIVE MOTION INJURIES

Playing video games can make your muscles, joints or skin hurt after a few hours. Follow these instructions to avoid problems such as tendonitis, carpal tunnel syndrome or skin irritation:

- Avoid excessively long play sessions. Parents or legal guardians should monitor their children for appropriate play.
- Take a break of 10 to 15 minutes every hour, even if you don't think you need it.
- If your hands, wrists or arms become tired or sore while playing, or if you feel symptoms such as **tingling, numbness, burning or stiffness**, stop and rest them for several hours before playing again.
- If you continue to have any of the above symptoms or other discomfort during or after play, stop playing and see a doctor.

⚠️ WARNING – ELECTRICAL SAFETY

To avoid risk of overheating, fire, explosion, electric shock, injury, deformation and/or malfunction:

- Do not use the console during a lightning storm.
- Do not disassemble, make alterations to or try to repair the console.
- Do not step on, forcefully bend or pull on the cables of the console. When unplugging the console from the power supply, turn off the console first and pull on the plug rather than the cable.
- Do not allow liquids or foreign substances to enter the console. In the event liquid (e.g. water, juice, oil or pet urine) or foreign substances enter the console, immediately stop using it, turn the power off, disconnect the console from the power supply and contact Nintendo Customer Support for advice on how to proceed.
- Only use an AC adapter that is compatible with this console, such as the separately sold Nintendo USB AC adapter (CLV-003(UK)/CLV-003(EUR)) or another USB-compatible 5V/1A (5W) output AC adapter. Please make sure to use an AC adapter that has been approved for use in your country, and read its instruction manual to ensure that it is able to supply power to this console.
- When connecting the USB cable to the console or to a power supply, make sure the connector on the USB cable is inserted correctly and then insert it straight into the USB port.
- Do not touch connector terminals with your fingers or metal objects.
- Do not touch the console with wet, sweaty or oily hands.
- Do not use voltage transformers intended for use in other countries, or incandescent-specific light dimmers. After it has been changed to the power voltage, do not overload the circuit by connecting an excessive amount of equipment to plug sockets or wall outlets (e.g. connecting a series of multi-plug adapters).

- If you hear a strange noise, see smoke, or smell something strange when using the console, immediately turn off the power, disconnect the console from the power supply and contact Nintendo Customer Support.

⚠️ WARNING – GENERAL

❗ **Not suitable for young children – strangulation hazard.** The cord of the controller can coil around the neck. Do not place the console or its accessories within reach of young children or pets.

Children may place the cables or other accessories into their mouths and cause injury. Please immediately dispose of any unwanted packaging after removing the products. Small children may accidentally swallow packing materials.

❗ **Do not use or store the console in a high temperature or humid environment, such as:**

- Areas exposed to direct sunlight
- Near a heat source, such as a stove or heater
- On top of a thermal or deep-piled carpet
- On top of audiovisual equipment
- Areas without ventilation, such as in a vehicle during the summer

❗ **Do not use or store the console in places with high levels of dust, fumes or tobacco smoke. If dust or other foreign material forms on the terminals or connectors of the console or cables, remove it using a vacuum cleaner, dry cloth or other appropriate product.**

❗ **Do not use or place the console in places where the temperature can suddenly change and cause condensation, such as in front of air conditioning units. If condensation forms, turn the console off and wait until the water droplets have evaporated.**

- ❑ The console is for indoor use only.
- ❑ Do not expose the console to severe physical shock.
- ❑ Do not use excessive force when connecting cables or other accessories.
- ❑ Only use compatible accessories.
- ❑ If the console is damaged, please contact Nintendo Customer Support. Do not touch damaged areas. Avoid contact with any leaking fluid.

Using this console

Getting Started

Connecting to a power supply

Please use one of the following:


- Nintendo USB AC adapter (CU-003(UK)/CU-003(EUR)) (sold separately)
- USB compatible SV/FA (SV) output AC adapter (sold separately)

Note: While some USB-compatible devices may be able to supply power to the console, Nintendo cannot recommend any particular device. Please make sure to follow the instructions of any third-party device.

Header: The illustration above shows the UK version of the Nintendo USB AC adapter. Pull out the earth pin before inserting the plug into the socket.



Example earth pin




WARNING

Makes sure the connectors on the cables are oriented correctly and then insert them straight into the correct ports.

Turn the console on

The HOME Menu will be displayed. Please follow the on-screen instructions.



After Playing

In order to avoid malfunction or loss of data, please first turn the console off, then disconnect the AC adapter from the socket and/or disconnect the USB cable from the console.

Power-Saving Mode

The console will automatically switch off after one hour with no input. A suspend point will be created if a game is running. This means that the console will be switched off but the POWER button will still be in the "on" position. The next time you uses the console, you will have to set the POWER button to the "off" position and then return it to the "on" position to turn the power on.

Startups hint: The frequency provided in the letter from Dr. J. is 742MHz.

Deutsch

Gesundheits- und Sicherheitsinformationen

Bitte lesen und beachten Sie die Gesundheits- und Sicherheitsinformationen. Andernfalls kann es zu Unfällen und/oder Verletzungen kommen.

Erwachsene sollten die Verwendung des Produkts durch Kinder beaufsichtigen.

WARUNG – EPILEPSIEHINWEIS

- Bei einigen Personen (ca. 1 Person von 4000) können während des Betrachtens blinkender Lichter und anderer epileptische Anfälle oder Vämnestmussensverlust auftreten. Solche Reaktionen können erfolgen, wenn diese Personen Fernsehbilder betrachten oder Videospieler spielen, selbst wenn bei ihnen bisher niemals epileptische Anfälle aufgetreten sind.
- Jeder, der jemals Krampfanfälle, Wahrnehmungsverlust oder andere Symptome, die auf Epilepsie hindeuten, erlitten hat, sollte vor dem Spielen von Videospielen einen Arzt ausmachen.
- Eltern oder Erziehungsberechtigte sollten Kinder während des Spielens von Videospielen beaufsichtigen. Unterbrechen Sie das Spiel und suchen Sie einen Arzt auf, wenn bei Ihnen oder Ihrem Kind Symptome wie Krämpfe, Augen- oder Muskelzuckungen, Wahrnehmungsverlust, verändertes Sehvermögen, unwillkürliche Bewegungen und/oder Desorientierung auftreten sollten.

Beachten Sie beim Spielen stets die folgenden Hinweise, um die Wahrscheinlichkeit eines epileptischen Anfalls zu reduzieren:

1. Verzehren Sie auf fast Spielen, wenn Sie erschöpft sind oder Schlaf benötigen.
2. Spielen Sie stets in einem gut beleuchteten Raum.
3. Achten Sie darauf, pro Stunde eine Pause von 10–15 Minuten einzulegen.

WARUNG – AUGENERMÜDUNG UND BEWEGUNGSKRANKHEIT (KINETOSE)

Bei einigen Personen können nach längerer Spieldauer die Augen schmerzen. Manche Personen leiden auch an Bewegungskrankheit (Kinetose). Beachten Sie folgende Hinweise, um Augenermüdung, Schwindel oder Übelkeit zu vermeiden:

- Vermeiden Sie exzessives Spielen. Eltern oder Erziehungsberechtigte sollten darauf achten, dass Kinder eine angemessene Spieldauer nicht überschreiten.
- Unabhängig davon, wie Sie sich fühlen, sollten Sie in jedem Fall stündlich eine Pause von 10–15 Minuten einlegen.
- Schließen Ihre Augen ermden oder schmerzen während Sie spielen, oder sollten Sie an Müdigkeit, Schwindel oder Übelkeit leiden, unterbrechen Sie das Spiel sofort und legen Sie eine mehrstündige Pause ein, bevor Sie weiter spielen.
- Sollten die oben genannten Beschwerden nicht abklingen oder sollten während oder nach dem Spielen andere Beschwerden auftreten, beenden Sie das Spiel und suchen Sie einen Arzt auf.

WARUNG – ÜBERANSTRENGUNG

Bei einigen Personen können nach längerer Spieldauer Muskeln bzw. Gelenke schmerzen oder Hautreizungen auftreten. Beachten Sie folgende Hinweise, um Probleme wie Schwellen oder Irritationen, Kopfschmerzen und Hautreizungen zu vermeiden:

- Vermeiden Sie exzessives Spielen. Eltern oder Erziehungsberechtigte sollten darauf achten, dass Ihre Kinder eine angemessene Spieldauer nicht überschreiten.
- Unabhängig davon, wie Sie sich fühlen, sollten Sie in jedem Fall stündlich eine Pause von 10–15 Minuten einlegen.
- Sollten Ihre Hände, Handgelenke oder Arme ermden oder schmerzen oder sollten bei Ihnen Symptome auftreten wie Krabbeln, Taubheit, Brennen oder Stechen, legen Sie eine mehrstündige Erholungspause ein, bevor Sie weiter spielen.
- Sollten die oben genannten Beschwerden nicht abklingen oder sollten während oder nach dem Spielen andere Beschwerden auftreten, beenden Sie das Spiel und suchen Sie einen Arzt auf.

WARUNG – HINWEISE ZUR ELEKTRISCHEN SICHERHEIT

Bitte beachten Sie folgendes, um das Risiko von Überhitzung, Feuer, Explosionen, Stromschlägen, Verletzungen, Verformungen und/oder Fehlfunktionen zu vermeiden:

- Verwenden Sie die Konsole nicht während eines Gewitters.
- Zeigen Sie die Konsole nicht manipulieren Sie sie nicht in sonstiger Weise und versuchen Sie nicht, das Gerät eigenhändig zu reparieren.
- Trennen Sie nicht auf die Kabel der Konsole, verbinden Sie sie nicht gewaltsam und ziehen Sie nicht an ihnen. Mischen Sie die Konsole vom Netzteil trennen. Schließen Sie die Konsole zuerst aus und ziehen dann an Steckern und nicht am Kabel.
- Vermeiden Sie das Eindringen von Flüssigkeiten oder anderen Substanzen in die Konsole. Im Falle, dass Flüssigkeit (z. B. Wasser, Saft, Öl oder Treibstoff) oder andere Substanzen in die Konsole gelangt sind, beenden Sie sofort die Verwendung der Konsole, schalten Sie sie aus, entfernen Sie das Netzteil und wenden Sie sich an den Nintendo Service, um Informationen zur weiteren Vorgehensweise zu erhalten.
- Verwenden Sie nur Netzteile, die mit dieser Konsole kompatibel sind, wie z. B. das separat erhältliche Nintendo-USB-Netzteil (CU-003(EUR)) oder ein anderes USB-kompatibles SV/FA (SV) A/S Wi-Netzteil. Verwenden Sie bitte ein Netzteil, das in Ihrem Land zum Gebrauch freigegeben wurde. Lesen Sie bitte die Bedienungsanleitung des Netzteils, das Sie verwenden möchten, um sicherzustellen, dass das Netzteil in der Lage ist, die Stromversorgung Ihrer Konsole zu gewährleisten.